The HUBBUB Aero Wheel Cover

Installation and Assembly Videos

PARTS LIST

Cover (1)
Inner Anchor Ring with V-notch (1)
Outer Retention Ring (1)
Anchor Clips (5)
Retention Clips/straps (5)

HOW TO ASSEMBLE AND INSTALL

Before assembly, account for all parts and make sure to assemble the wheel cover at room temperature. Also note that each ring comes with a metal securement sleeve and five equidistant flattened spots along their circumference

1. Lay the **Inner Anchor Ring with V-notch** on a flat surface.

   - Lift the ring and place an **Anchor Clip** (orange pad down with loop and prong towards the center) under the ring at each of the five flattened spots. Align the center of the clip to a flattened spot and clip it to the ring. It should audibly “snap” onto the ring at the center of the clip. Complete all five.

   - Turn the ring over so the orange pads face up.

2. Place the **Outer Retention Ring** on a flat surface with the **Retention Clip Straps** up and orange pad facing outward, Before snapping them in place, make sure the center of each clip is aligned with a flattened spot on the ring. Complete all five.

You are now ready to attach the rings together to form the dual ring assembly.

3. Hold the assembled **Retention Ring** and flip it over. Thread each strap over and through the **Anchor Clip** and secure the strap at the outermost hole to the prong. Complete all five. You are now ready to attach the rings together to form the dual ring assembly. Make sure to orient the securement sleeves away from each other.

You are now ready to position the dual wire frame assembly into the wheel.

4. Locate the tire valve stem. Center the **Inner Anchor Ring with V-notch** at, but not touching, the valve stem. While holding the V-notch, push the inner ring behind the drop center (contour of the wheel).

5. Once all the anchor clips are over the drop center, begin to cinch up the straps (in an opposing sequence) as you align the five **Retention Clips** equidistant from wheel’s edge.

6. For final fitment, make sure all the anchor clips are seated and that the same number of holes are exposed on all the straps.

7. Position the **Cover** with each of the five orange grommets aligned with each of the retention clips. With both hands, rotate the cover clockwise to secure the cover into all of the clips. There should be an audible sound as the cover clips into place. Tap the cover lightly at its center. When properly assembled and installed, all orange components should be hidden.

To remove the **Cover**, place a finger in one of the two holes and pull it from the wheel.